



NOTES:

1. CONCRETE ANCHOR WALLS (CLASS 3000) SHALL BE CONSTRUCTED USING FORMS WHEN SEWERS, STORM DRAINS, AND OTHER PIPELINES ARE CONSTRUCTED WITH SLOPES 20 PERCENT OR GREATER. REMOVE FORMS PRIOR TO BACKFILLING TRENCH.
2. SPACING OF ANCHOR WALLS SHALL BE:

<u>SLOPE:</u>	<u>SPACING:</u>
20-34%	35 FEET
35-50%	25 FEET
50+ %	15 FEET OR CONCRETE ENCASEMENT

CITY OF FLORENCE STANDARD DRAWING	
PIPE ANCHOR DETAIL	
DATE: MARCH 2007	DRAWING NO. F-303